

# Installation Instructions



Instrucciones de Instalación / Instructions d'installation /  
Installationsanleitung / Istruzioni per l'installazione

# TRIPP LITE SERIES



## N286 Series Optical Transceivers

Transceptores ópticos de serie N286 / Émetteurs-récepteurs optiques de la série N286 /  
Optische Empfänger der Serie N286 / Ricetrasmittitori ottici serie N286

Transceiver with MTP/MPO Connection / Transceptor con conexión MTP/MPO / Émetteur-récepteur avec connexion MTP/MPO /  
Empfänger mit MTP/MPO-Anschluss / Ricetrasmittitore con connessione MTP/MPO



Transceiver with LC Connection / Transceptor con conexión LC / Émetteur-récepteur avec connexion LC /  
Empfänger mit LC-Anschluss / Ricetrasmittitore con connessione LC



Powering Business Worldwide

Eaton  
1000 Eaton Boulevard  
Cleveland, OH 44122  
United States  
Eaton.com

© 2024 Eaton  
All Rights Reserved  
Publication No. 23-08-311 / 93-4924\_RevA  
May 2024

Eaton has a policy of continuous improvement. Specifications are subject to change without notice. Photos and illustrations may differ slightly from actual products.

Eaton is a registered trademark.

All trademarks are property of their respective owners.